




UBC

FL000 SERIES HOUSING



PART NO	a mm	e mm	g mm	l mm	s mm	b mm	Wgt g
FL000	60	45	5.5	11.5	7	36	37
FL001	63	48	5.5	11.5	7	38	46
FL002	67	53	6.5	13	7	42	54
FL003	71	56	7	14	7	46	60
FL004	90	71	8	16	10	55	103
FL005	95	75	8	16	10	60	113
FL006	112	85	9	18	13	70	176

SUITABLE BEARING SERIES K000, U000